

# EV/HEV


## BATTERY MODULE



Module Fuse



Cooling Plate



Monitoring Busbar

## BATTERY PACK / BDU



Hybrid pyro-fuse



Main fuse

## JUNCTION BOX / BDU



Auxiliary fuse

## INVERTER / PDU



Capacitors



Cooling



Busbar


## CHARGING STATION




SPD




Fuse



Cooling



Busbar



PDU: POWER DISTRIBUTION UNIT BDU: BATTERY DISCONNECT UNIT SPD: SURGE PROTECTION DEVICE